

# WATERPROOFING WORK AT PODIUM USING HIND HYDROLAST-2K (HP)

## APPLICATION INSTRUCTIONS

### STEP - 1

#### SURFACE PREPARATION

1. The surface must be made sound & free from dust, dirt & loose particles by thoroughly wire-brushing it.
2. If require grinder may be used. Clean the dust by vacuum cleaner.
3. Wash the surface with water. Oils & grease must be removed by degreasing solvent.
4. If any damage or existing crack are found on the surface, to be repaired by cutting 1"- V groove and filling the same using 'Hind Patch R'- Fiber Reinforced Repair Mortar(1kg Patch-R:160 gm water) over a bond coat of 'Hind Styrene BR' admixed with water & cement in the ratio of (1 part Hind Styrene BR: 1 part Water: 3 Parts Cement)
6. All pipe inserts in floors & walls should be properly sealed with HIND HSMC (1 kg HSMC: 160 gm water) over a bond coat of epoxy bonding agent HIND BOND EBA modified cement sand mortar.

### STEP - 2

#### NOZZLE GROUTING

1. Fixing PVC nozzles all along the construction joints @ 800 mm c/c on the wall and @ 1000 mm c/c in grid pattern on the base slab, grouting for injection of cement slurry admixer with Expanding grout Admixture HIND PLAST EGA (0.5 to 0.6 kg per 100 kg cement and w/c ratio 0.36 to 0.4).
2. Identification of the honeycomb area, if any, apart from the Construction Joints and fixing additional. PVC Nozzles for Injection Grouting.
3. Pressure Injection Grouting by means of a pressure pump applying pressure @ 2.5Kg/cm<sup>2</sup> with Cement Slurry admixed with 'Hind Plast EGA'- Non Shrink Grouting Compound through the PVC Nozzles fixed and properly sealing them after grouting work is completed.
4. After the grouting operation is over, the PVC Nozzles fixed are cut off from the edge and sealed with cement sand mortar (1:3), admixed with HIND STYRENE BR modified (5-10%) weight of cement.

### STEP - 3

#### WATERPROOFING COATING

1. Supplying and applying one coat of waterproof coating HIND SBRLATEX (1 part Hind Styrene BR: 1 part Water: 3 parts Cement) on the prepared surface on floors & up to 1m height on walls.
2. Supplying and applying two coats of waterproof coating HIND HYDROLAST-2K (HP) on the prepared surface on floors & up to 1m in height on walls. Consumption of the product is 1.2 to 1.6 Kg /m<sup>2</sup> in two coats with Hind Fiber Glass. Coverage depends on the surface's porosity and texture. Thickness of Layer 1.5 - 2mm, average thickness with Hind Fiber Glass. All substrates should be in SSD condition prior to using Hind Hydrolast 2K (HP).
3. Glass fiber wire mesh should be placed on the 1st coat till the coating is in a wet condition.
4. Allow the surface to dry.
5. After getting 1st coat completely dried 2nd coat should be applied to make a sandwich coating system.
6. Dry sand has to be sprinkled on the coated surface until the 2nd coat is in a tacky condition to provide a key for the subsequent plaster.

### STEP - 4

#### PROTECTIVE PLASTER (ONLY WALL)

1. Application of 1:2:2 Stone plaster for a thickness of 15 - 20 mm in the ratio (1 part Cement: 2 parts Sand: 2 parts 6mm stone Aggregate), admixed with HIND PLAST IWA (100ml for 50kg cement) & HIND PP FIBER (125gm for 50kg cement), followed by a neat cement finish over the plastered surface when it is green.

OR

#### PROTECTIVE SCREED (FLOOR)

1. Providing and laying of 75mm average thick screed concrete (1:2:4) in proper slope with HIND PLAST IWA (100ml for 50kg cement) & HIND PP FIBER (125 gm for 50 kg cement) followed by neat cement finish over the plastered surface when it is green.